




7527.0030

XXX

Onderdelen informatie
Erzatzteil information
Spare part information
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
01	7527.0030.01	The Body	
02	7527.0030.02	Compressor compartment back board	
03	7527.0030.03	Compressor compartment net board	
04	7527.0030.04	Exhaust plate fortified board	
05	7527.0030.05	Baffle	
06	7527.0030.06	Wire condenser	
07	7527.0030.07	Condenser fan motor	
08	7527.0030.08	Condenser fan motor support	
09	7527.0030.09	Filter	
10	7527.0030.10	Fliter cilp	
11	7527.0030.11	Compressor fixing plate	
12	7527.0030.12	Water Tray	
13	7527.0030.13	Evaporating tube	
14	7527.0030.14	Compressor	
15	7527.0030.15	Power wire with plug	
16	7527.0030.16	Junction box	
17	7527.0030.17	Ballast	
18	7527.0030.18	Thermostat with displayer	
19	7527.0030.19	Digital Displayer	
20	7527.0030.20	Connecting Cable	
21	7527.0030.21	Light switch	
22	7527.0030.22	Displayer fixing plate	
23	7527.0030.23	Adjusting foot	
24	7527.0030.24	Exhaust plate assemblies	
25	7527.0030.25	Pilaster	
26	7527.0030.26	Starter	
27	7527.0030.27	Starter holder	
28	7527.0030.28	Light tube fixing plate	
29	7527.0030.29	light cover clipplate	
30	7527.0030.30	lamp holder	
31	7527.0030.31	Light tube	
32	7527.0030.32	Transparent light cover	
33	7527.0030.33	Evaporator fan motor plate	
34	7527.0030.34	Fan motor plate support	
35	7527.0030.35	Evaporateur fan motor	
36	7527.0030.36	Evaporator fan motor cover	
37	7527.0030.37	Evaporator baffle support	
38	7527.0030.38	Evaporator baffle	
39	7527.0030.39	Evaporator	
40	7527.0030.40	Evaporator support	
41	7527.0030.41	Shelf	
42	7527.0030.42	K Clip	
43	7527.0030.43	Door hinge	



Onderdelenlijst 7527.0030

POS:	Art.No.:	Omschrijving:	Aantal:
44	7527.0030.44	Door	
45	7527.0030.45	Door seal	
46	7527.0030.46	Appliance fixing plate	
47	7527.0030.47	Handle	